

# Partizan STD-2MP

## Face recognition and temperature measurement access control device manual



BE DIFFERENT  
LEAD WITH IT


# Contents

1. System Login .....	3
2. Main Interface .....	3
3. Settings .....	4
3.1. System Parameter .....	4
3.1.1. System Information .....	4
3.1.2. User Management .....	4
3.1.3. Time Settings .....	5
3.1.4. Wired Network Parameter.....	6
3.1.5. TCP ports settings .....	6
3.1.6. Face Recognition• Parameter Settings .....	7
3.1.7. Analytics and Alarm Settings .....	10
3.1.8. Access Control settings .....	12
3.1.9. Email settings.....	14
3.1.10. Internal storage.....	15
3.1.11 Audio settings .....	15
3.1.12 Factory Reset .....	16
3.1.13. Device Restart.....	16
3.2. HTTP Upload Settings .....	17
3.3. Software Upgrade .....	19
3.4. Video settings .....	20
3.5. Video stream.....	21
3.6. RTSP settings.....	22
3.7. FTP settings.....	23
4. List Management .....	24
4.1. List Management .....	24
4.2. Batch import .....	26
5. Report .....	27
6. Attendance .....	28

---

## 1. System Login

Open a browser (Internet Explorer) and enter IP address of the access control attendance panel. e.g.:  
Default address of device: 192.168.1.88. While logging in to the page for the first time, enter a username and a password (default username: admin, password: admin), as shown in Pic. 1.




The login interface features a dark blue header with the Partizan logo and the text 'Face Recognition'. Below the header, there are two input fields: 'User Name:' with the value 'admin' and 'Password:'. A large blue 'Login' button is positioned at the bottom of the form.

Pic. 1

## 2. Main Interface

The main interface is shown in Pic. 2:




Pic. 2

## 3. Settings

### 3.1. System Parameter

#### 3.1.1. System Information

The setup interface of system information and basic parameters of system parameters of the access control attendance panel are shown in Pic. 3.1.1:



Pic. 3.1.1


【System】 Displays device name, device number, core version and other information. Device name can be user-defined.

After parameter settings, click on 【Save】 .

【Language】 After other languages are selected, close IE and log in to device again.

#### 3.1.2. User Management

The setup interface of user management of the access control attendance panel is shown in Pic. 3.1.2:



Pic. 3.1.2

Three users can be set for every access control attendance panel, one is administrator and two are ordinary users.

Administrator permission: All functions and parameters of access control attendance panel can be set.


After parameter settings, click on **Save**.



**Important: Username and password must be a character string with 1-16 characters. Please pay attention to capital and lower-case form.**

### 3.1.3. Time Settings

The setup interface of Time Settings of the access control attendance panel is shown in Pic. 3.1.3:



Pic. 3.1.3

**Date** Display current date and time of device.

**NTP server** After this function is enabled, the access control attendance panel will check the clock of the access control attendance panel using NTP server at fixed time according to set time zone.

**Synchronize with Local PC** Click on "Synchronize with local computer" and device date and time will be synchronous with computer date and time.

**Set the time Manually** Click on manual settings to set up device date and time under current time of device.


**Time zone conversion** Time zone definition switch (1/2 is optional)

**RTC switch** RTC switch, default: ON.

After parameter settings, click on **Save**.

## 3.1.4. Wired Network Parameter

The setup interface of wired network parameters of the access control attendance panel is shown in Pic. 3.1.4:



Pic. 3.1.4

**【DHCP Enable】** If DHCP function of Router is enabled, the access control attendance panel will automatically obtain the IP address from the router.

**【IP】** Set up IP of the access control attendance panel .

**【Subnet Mask】** Default code: 255.255.255.0 (it cannot be modified by client).

**【Gateway】** Set up gateway IP of the access control attendance panel. e.g.: If a device will be connected to a public network through Router, gateway IP should be set as Router IP of the public network.


**【MAC】** MAC address of access control attendance panel (it cannot be modified by client).

After parameter settings, click on **【Save】** and restart the device to validate them.



**Note: After network parameters are modified and saved, the device will be restarted automatically. If the device is used in a LAN, please pay attention to prevent conflict between this device's IP address and IP addresses of other devices or computers in the LAN.**

## 3.1.5. TCP ports settings



Pic. 3.1.5

**【Data port】** – Port for data transmission

**【Web port】** – Access port to web interface

**【ONVIF port】** – Port connection through Onvif protocol

### 3.1.6. Face Recognition • Parameter Settings

【Enable】 It is used to enable face recognition algorithm. Face recognition can be conducted and other parameter settings can be validated only when ON/OFF is ticked. It is ON by default.

ers
Time
Network
Email
Face recognition
Analytics and Alarms

Enable ☒

Time schedule 1 ☒ 0 : 0 -- 23 : 59

Time schedule 2 ☒ 0 : 0 -- 23 : 59

Sensitivity

9

Snapshot mode single mode

Snapshots quantity 8

Snapshot interval 5 (1~1500)

Face recognition max. pixels 500 (300~500)

Face recognition min. pixels 70 (30~300)

Face temperature testing min. pixels 100 (0~500)

Face scene Lobby scene

Face Tracking On

FTP Upload On

FTP upload image type Face image

FTP upload image quality 99 (1~99)

Human appearance analytics On

Human verification Off

Function priority Temperature first

Save Restore Default

Pic. 3.1.6-1

【Time schedule】 It is deployment time and user can define two periods. To validate it, tick 【Time schedule】 .

Default: Two periods are enabled. Default time: 00: 00-23: 59.

Enable ☒

Time schedule 1 ☒ 0 : 0 -- 23 : 59

Time schedule 2 ☒ 0 : 0 -- 23 : 59

Pic. 3.1.6-2

【Sensitivity】 Setting range: 0-10.

Sensitivity refers to sensitivity of face recognition. The higher sensitivity would result into lower missing report rates and there would be higher probability of re-capturing and accidental capturing. The lower sensitivity would give high capturing rate. However, missing capturing will be caused if sensitivity is too low. Generally, the best effect can be achieved when sensitivity is 3-5.

Sensitivity

Pic. 3.1.6-3

【Snapshot mode】 Single mode: Used cooperatively with 【Snapshots times】 and 【Snapshot interval】 .

Snapshots quantity

Snapshot interval  (1~1500)

Pic. 3.1.6-4



**Note:** Gate of trial site. When many people pass the gate, only the first person (face which has the maximum pixel in the screen) is captured. According to set frame interval, a face will be captured at certain frames and uploaded to FTP server. Only one face will be displayed on the screen.

【Face recognition max. pixels】 Setting range: 300-500. When face pixels in the screen are greater than the set value (maximum pixel of face recognition), face will not be captured.

Face recognition max. pixels  (300~500)

Pic. 3.1.6-5



【Face temperature testing min. pixels】 Setting range: 0-500. When face pixels in the screen are greater than the set value (minimum pixel of face temperature measurement), temperature will not be measured.

Face temperature testing min. pixels  (0~500)

Pic. 3.1.6-6

【Face recognition min. pixels】 Setting range: 30-300. When face pixels in the screen are greater than the set value (minimum pixel of face recognition), face will not be captured.

Face recognition min. pixels  (30~300)

Pic. 3.1.6-7

【Face scene】 This parameter is used to adopt different face exposure strategies for different application scenarios. There are two types of application scenarios: Ordinary scenario and lobby scenario.

Default: 【Lobby scene】 .

**Ordinary scenario:** Applicable to conventional environment.

**Lobby scenario:** Applicable to backlight environment.

Face scene ☐ Common scene ☒ Lobby scene

Pic. 3.1.6-8

【Face tracking】 This parameter is used for superposition of face tracking boxes. It is ON by default.

【FTP upload】 This parameter is used to set up FTP server to upload human face pictures. It is ON by default.

For detailed configuration method, refer to 5.4.7.

FTP Upload

Pic. 3.1.6-9

【FTP upload image type】 On FTP, picture can be uploaded in the format of 【Upload face】 or 【Upload face and original picture】 .

【FTP upload image quality】 Quality of picture uploaded by FTP is 99 by default. The larger the value is, the better the picture quality.

【Human appearance analytics】 It is ON by default.

【Human verification】 It is OFF by default.

【Function priority】 Preferred speed or preferred vivo is optional. Default: Preferred speed.

## 3.1.7. Analytics and Alarm Settings

Alarm of whitelist and blacklist can be set.

System
Users
Time
Network
Email
Face recognition
Analytics and Alarms
Access control

Alarm <input checked="" type="checkbox"/>	Known Person Alarm <input checked="" type="checkbox"/>	VIP List Alarm <input checked="" type="checkbox"/>	Unknown Person Alarm <input type="checkbox"/>
IO Output	<input checked="" type="checkbox"/> Continuous	Alarm output <input type="text" value="1"/> (1~60)S	IO Output Type <input type="text" value="On"/> *
Recognition Mode	Single recognition		
Face similarity recognition ratio	<input type="text" value="75"/> (1-100)		
ID similarity	<input type="text" value="60"/> (1-100)		
Working mode	Face recognition + Temperature measurement		
Face mask detection	<input type="text" value="On"/> without mask <input type="text" value="Do not open the door"/>		
Temperature correction	Smart measurement temperature correction gap <input type="text" value="0.0"/>		
Door opening with abnormal temperature	<input type="text" value="Off"/>		
Abnormal temperature level	<input type="text" value="37.3"/> (1-100)		
Temperature scale	Celsius		
Time frame without temperature measurement	<input type="checkbox"/> <input type="text" value="0"/> : <input type="text" value="0"/> -- <input type="text" value="23"/> : <input type="text" value="59"/>		

Save
Restore Default

Pic. 3.1.7-1

【Alarm】 ON or OFF is optional (it is ON by default)

【Alarm of Known and VIP Person】 ON or OFF is optional. VIP list alarm (it is ON by default)

【IO output】 IO output type is optional (continuous output is selected by default)

【Alarm output】 Select output alarm duration

【IO output type】 IO output type is optional (it is Normal-Open (NO) on by default)

【Recognition mode】 Select mode of access control attendance panel (it is single face recognition by default)

System	Users	Time	Network	Email	Face recognition	Analytics and Alarms	Access control
--------	-------	------	---------	-------	------------------	----------------------	----------------

Alarm <input checked="" type="checkbox"/>		Known Person Alarm <input checked="" type="checkbox"/>		VIP List Alarm <input checked="" type="checkbox"/>		Unknown Person Alarm <input type="checkbox"/>	
IO Output	<input checked="" type="checkbox"/> Continuous	Alarm output <input type="text" value="1"/> (1~60)S		IO Output Type	<input type="text" value="On"/> *		
Recognition Mode	<input type="text" value="Single recognition"/>						

Pic. 3.1.7-2

【Interval recognition】 If face picture can be matched in the list within the set recognition times, recognition will be stopped. If face picture is not matched in the list within the set recognition times (e.g.: set times recognition value is 5 and face is matched within 5 times of capturing, contrast information will be displayed and recognition will be stopped. If face is not matched after 5 times of recognition, recognition will be stopped) (Only when recognition mode is times recognition).

【Single recognition】 Similar to the mode whose times recognition value is 1, but number of pictures is recognized. (Single face recognition is recommended for access control attendance panel)

【Continuous recognition】 Face will be recognized according to set capturing mode

【Face similarity recognition ration】 Select similarity of face contrast. If the set contrast similarity is too low, error may occur (contrast similarity is 75 by default)

【ID similarity】 Select ID Card contrast similarity. If the set contrast similarity is too low, error may occur (contrast similarity is 60 by default)

【Working mode】 Select mode of access control attendance panel from face recognition, temperature detection, face + temperature detection, ID Card + face + temperature, ID Card + face, ID Card or whitelist + temperature and ID Card or whitelist. Mode is temperature detection by default.

Working mode	<input type="text" value="Face recognition + Temperature measurement"/>
--------------	---

Pic. 3.1.7-3

【Face mask detection】 ON or OFF is optional. It is OFF by default (note: If mask detection is OFF, contrast record and mask use shall be None).

【Temperature correction】 Intelligent algorithm and low temperature algorithm. Under intelligent algorithm mode, compensation temperature can be set. After that, increase the set compensation temperature after temperature is measured each time; low temperature algorithm means to convert unreasonable body temperature value into normal body temperature automatically under low temperature.

【Door opening with abnormal temperature】 ON or OFF is optional in case of high temperature alarm. It is OFF by default. If high temperature is detected at ON, namely alarm signal will be outputted when the temperature exceeds the threshold.

【Abnormal temperature level】 Temperature threshold can be set. If temperature exceeds the threshold when working mode includes temperature detection, an alarm will be given. Temperature threshold is 37.3 by default.

【Time frame without temperature measurement】 Deployment can be conducted within the specified time (deployment time is 00:00-23:59 by default and it is ON by default)

### 3.1.8. Access Control settings

Set up related information of access control; Wiegand output control, white light control, same face filtration and screen display mode can be set;

gnition

Analytics and Alarms

Access control

Restore

Wiegand output	Off
White light control	Energy saving mode
Monitor mode	Energy saving mode
One person capturing time	3 (1-10s)
Temperature measurement mode	Precision mode
Date Format	YYYY-MM-DD
Comparison record storage	All records

Save

Pic. 3.1.8-1

【Wiegand output】 : it can set up Wiegand output off or on, or choose Wiegand 26 or Wiegand 34 which is optional;

Wiegand output	<div>Off</div>
White light control	<div>WG26</div> <div>WG34</div>
Monitor mode	<div>Energy saving mode</div>
One person capturing time	<div>3</div> (1-10s)

Pic. 3.1.8-2

【White light control】 : White light is normally on, white light time control and white light is normally off are optional; White light time control is set accordingly with daytime/nighttime on the right. Default: White light is normally on.

Wiegand output	<div>Off</div>	
White light control	<div>White light for limited time</div>	Turn day <div>0</div> : <div>0</div> : <div>0</div> Turn night <div>23</div> : <div>59</div> : <div>59</div>
Monitor mode	<div>Energy saving mode</div>	
One person capturing time	<div>3</div>	(1-10s)

Pic. 3.1.8-3

【Monitor mode】 : Always on and screen display is closed if there is nobody; Default: Screen display is closed within 10s if there is nobody.


Wiegand output	<div>Off</div>	
White light control	<div>White light for limited time</div>	Turn day <div>0</div> : <div>0</div> : <div>0</div> Turn night <div>23</div> : <div>59</div> : <div>59</div>
Monitor mode	<div>Always on</div> <div>Energy saving mode</div>	
One person capturing time	<div>3</div>	(1-10s)

Pic. 3.1.8-4

Same face filtration: Face filtration time of the same list, it is 3s by default.

### 3.1.9. Email settings

Parameters' settings for notifications to be sent on E-mail




Pic. 3.1.9-1

Specifying Email address.

Enter the recipient's email address.

To configure outgoing mail settings click on the icon [【Add sender】](#)



Pic. 3.1.9-2

[【From】](#) Enter sender's mail

[【Password】](#) Enter authorization password for the mailbox

[【MAIL Title】](#) Mail title

[【SMTP Port】](#) Specify mail server authorization port

[【SSL】](#) Activate encryption if necessary

【Push type】 Specifying type of notification required to be sent

Push type

None  
Abnormal temperature notification  
No face mask notification  
Visitor notification  
Event list notification  
All notifications

Pic. 3.1.9-3

### 3.1.10. Internal storage

System
Users
Time
Network
TCP ports
Email
Face recognition
Analytics and Alarms
Access control
Internal Storage
Audio

Choose	No.	Total Size (Mb)	Free Space (Mb)	Status
<input checked="" type="radio"/>	1 HSD	14800	13650	formatted

Format
Refresh

Pic. 3.1.10

This tab contains information about the number of storage devices, their size and status. It is possible to select the desired type and format it to fit the device format.

### 3.1.11 Audio settings

To activate the audio input, click 【Enable】

System
Users
Time
Network
TCP ports
Email
Face recognition
Analytics and Alarms
Access control
Internal Storage
Audio
R

Enable ☒

Audio Input

Compression Type

Audio Bitrate

Sampling Rate

Input Volume

Output Volume

Save

Pic. 3.1.11

【Audio Input】 – Selection of different input signal types. Available Connection options: microphone or a linear audio signal.

【Compression Type】 – Selection of audio compression types. Available audio-formats: AAC, G.726, G.711A and G.711U

## 3.1.12 Factory Reset

The setup interface of factory reset of the access control attendance panel is shown in Pic. 3.1.11:



\* By clicking this button you will restore device to the factory settings.


Restore factory settings

Pic. 3.1.12-1

Click on **Restore factory settings** and enter a password according to prompt message to restart the device and restore factory settings.

**Network** Tick to restore default network parameters. It is 192.168.1.88 by default.

**User Name** and **password** Tick to restore default username and password. It is admin/admin by default.



Enter password!

Restore: ☐ Network

☐ User Name

Password

Submit

Pic. 3.1.12-2

## 3.1.13. Device Restart

The setup interface of device restart of the access control attendance panel is shown in Pic. 3.1.12:



Restart The System Automatically

Never At 00:00

\* By clicking this button you will restart device manually.

Restart

Pic. 3.1.13


Automatic system restart - select a period to restart the device automatically.

**Manual system restart** Click **Restart** to enter a password according to prompt message to restart the device.



## 3.2. HTTP Upload Settings

When HTTP transmission mode is adopted for servers relating to the access control attendance panel, set up relevant server parameters in the menu, as shown in Pic. 3.3 (picture version is HTTP version V1.1.14 by default. HTTP version can be modified according to actual need. The device will be restarted after modification).



Pic. 3.2

【HTTP uploading】 Switch to upload data on server.

【Uploading address】 Server address for receiving information

【Uploading type】 Control of uploaded results type among successful uploads, all people upload, blacklist upload, whitelist upload, VIP list upload, stranger upload and non-whitelist upload. It is successful upload by default.

【Information content】 FaceInfo and CompareInfo are optional. Both should be selected as suggested.

【Image content】 Picture upload is optional among face picture, background picture and list picture.

【**Uploading attempts**】 Number of Re-uploading times when records are not uploaded successfully. It is 0 by default.

【**Registration**】 Switch for whether-to upload registration information.

【**Registration information upload address**】 Server address receiving registration information.

【**Heartbeat upload**】 Switch for whether-to upload heartbeat information.

【**Heartbeat information upload address**】 Server address receiving heartbeat information.

【**Heartbeat interval**】 Heartbeat interval time, unit: Second.

【**Instruction address acquisition**】 Address for acquiring instructions.

【**Instruction acquisition interval (s)**】 Time interval for acquiring instructions, unit: Second.

【**Active obtain the task address**】 Address for actively acquiring tasks.

【**Address to report tasks result**】 Address for reporting task result.

【**Sign verification**】 Sign verification ON/OFF. Default: OFF.


【**Operation mode**】 Offline mode and online mode are optional. Default: Offline mode.

【**HTTP version**】 HTTP version can be modified according to actual need and the device will be restarted after modification.

After parameter settings, click on **【Save】** .

### 3.3. Software Upgrade

The software upgrade interface of the access control attendance panel is shown in Pic. 3.4:



Pic. 3.3

**【Upgrade】** Click on “Browse” to select a correct upgrade file (core file, suffix is .uot) and click on "Upgrade" for upgrading. Percentage will be displayed in this process and the access control attendance panel will be restarted automatically after upgrade. Log in to the device again, enter the software upgrade page and check whether core version is the version upgraded.




**Important:**

1. Please ensure power and network of the access control attendance panel are not cut off in the upgrade process.
2. For Windows7 system users, please set up IE parameters according to prompt message below before upgrade; otherwise, the bar showing the process percentage will not be displayed. Steps: Open IE browser-tool-Internet option-safety-user-defined level-other-local directory path is included when file is uploaded to enabled server

### 3.4. Video settings

Image settings such as Brightness, Contrast, Saturation, etc.



Pic. 3.4

【Mirror】 – On/Off of mirror image

【LSC】 – Changing of Image formats


【3D-DNR】 – Digital noise reduction

【Flip】 – Flipping of image up/down

【Monitor frequency】 – Selection of frequency according to the regional power standards

## 3.5. Video stream

Settings for encoding of Primary and Secondary video streams.



Pic. 3.5

【Profile】 - Coding Profile Selection

【Coding】 – Compression coding selection H.264\H.265\MJPEG

【Resolution】 – Setting the resolution of the video stream

【Quality】 – Quality of video stream translation


【Bitrate type】 - CBR - constant bitrate of stream transmitted by the camera to network. VBR - bitrate varies depending on the picture in the frame

【Bitrate】 – Setting the maximum bitrate transmitted by the camera

【Frame rate】 – Setting the FPS for video stream. Available from 1 to 25fps

【GOP】 – Number of reference frames for coding

### 3.6. RTSP settings



Pic. 3.6


To switch on RTSP, click **【Enable】**

**【Authentication】** – Connection of RTSP stream using authentication

**【Onvif Password Enable】** – Connection through Onvif protocol using authentication

### 3.7. FTP settings

FTP server settings



Pic. 3.7

【Server URL】 – Network address of server for downloading files

【Server port】 – Server port

【FTP Catalog】 – Download path to catalogue on server where files are downloaded


【User name】 – Login for server access

【Password】 – Password for server access

## 4. List Management

### 4.1. List Management

The face library added can be searched and whitelist can be added to the library in different ways



Pic. 4.1-1

#### 1. Face list is searched in different ways


**【General search】** Carry out accurate search through start time, finish time, list type, sex, age and access card number.

**【Name search】** Carry out search of name using the name input box below.

**【Duplicate ID number search】** Carry out search according to repeated ID number.

**【Search for duplicate access card number】** Carry out search according to repeated access card number.

#### 2. Add whitelist by **【List management】** as follows



Pic. 4.1-2



Step 1: Click on Add list

Step 2: Click on Browse and select a picture to be imported according to storage path

Step 3: Select access card number generation method among public card number, automatic generation and manual input.

Step 3: Input picture name, ID number and other related information.


Step 4: Click on Save



**Note: Picture name and numbering rule: Picture number cannot be repeated**

## 4.2. Batch import

Batch import can be used to refresh list and import whitelist and VIP list by batches



Pic. 4.2-1



The screenshot shows the 'Batch import' form. It includes a file upload section with a 'Choose File' button and a note '\* Max size is 960x960!'. The form contains several input fields and dropdown menus for user information: Type (Whitelist), Name, Gender (Male), Nation, Certificate type (ID card), ID number, Date of birth, Phone number, City, Address, IC, and Note. There are also fields for 'Access control' (public card nur) and 'Person type' (Permanent). At the bottom, there are 'Save' and 'Cancel' buttons.

Pic. 4.2-2

Step 1: Click on Batch import

Step 2: Click on Browse and select a picture to be imported according to storage path


Step 3: Select access card number generation method among public card number, automatic generation and manual input.

Step 3: Select type of list to be imported

Step 4: Click on Save

## 5. Report

Record list includes main picture (existing picture or stranger's on-site picture), name, number, list, body temperature, time and details. Details include similarity, visit times, first visit time, mask use condition and body temperature detection result (details of stranger just include mask use condition and body temperature detection result). The latest 10000 records can be queried according to time, list type, name, number and other query conditions.




The screenshot shows the 'Report' section of the PARTIZAN Face Recognition software. The top navigation bar includes 'Face Recognition', 'Config', 'Database', 'Report' (active), and 'Attendance'. The left sidebar has a 'Report' button. The main content area has a red instruction: 'Double-click to any event to check more details about related person.' Below this is a form to create a customized report with fields for date range (2020-06-02 00:00 to 2020-06-03 23:59), list type (ALL), name, and serial number. A 'Create report' button is on the right. Below the form is a table with columns: Photo, Name, Serial number, List type, Body temperature, time, IC, and Description. The table is currently empty. At the bottom, there are links for 'Last page', '1 / 0 Move to this page', and 'Next page'.

Pic. 5

## 6. Attendance

Attendance record of any day or any period can be viewed



The screenshot shows the 'Attendance Reports' section of the PARTIZAN Face Recognition software. The interface includes a top navigation bar with 'Face Recognition', 'Config', 'Database', 'Report', and 'Attendance' (highlighted). Below this, the 'Attendance Reports' sidebar is visible. The main content area contains several form fields and buttons:

- Set particular day:** A dropdown menu currently set to 'Sunday'.
- Working hours:** A time range selector showing '06:00 - 09:00'.
- Off-hours:** A time range selector showing '18:00 - 23:59'.
- Set multiple days:** A button to configure multiple days.
- Working days:** A row of checkboxes for 'Monday', 'Tuesday', 'Wednesday', 'Thursday', 'Friday', 'Saturday', and 'Sunday'.
- Period selection:** Two date pickers showing '2020 - 06 - 03' and '2020 - 06 - 03'.
- Name and Serial number:** Two input fields for searching by name or serial number.
- Attendance status:** A dropdown menu set to 'all'.
- Report type:** A dropdown menu set to 'record'.
- Buttons:** 'Save', 'Default', 'Create report', and 'Set multiple days'.

At the bottom, there is a table header with columns: 'Photo', 'Name', 'Serial number', and 'Description'.

Pic. 6

1. Time and workday settings, any period of a day can be set as attendance time and any day of a week can be set as workday

2. Query condition:

1. Period query: Enter any period to view attendance record of the designated period

2. Attendance query: Select any parameter to view attendance record for the designated status

3. Name and number query: Enter name or number of any existing person to find name and number of this designated person